



## INSTALLATION INSTRUCTIONS

### IC 9000 SERIES HARDTOP COVER

1. Unlatch all connections of Hardtop from vehicle.
2. Lift front edge of hardtop (by windshield) slightly and slip cover onto the hardtop so that the front edge fits into the pocket of the leading edge of the cover. Make sure the front edge of the cover is flush with the front edge of the hardtop on both the driver and passenger sides.
3. Pull the cover back towards the rear of the vehicle.
4. Slightly lift the rear edge of hardtop at driver's side and pass the lower portion of cover (from inside passenger compartment if you have not removed hardtop from car) under and around back edge of hardtop. Fasten hook and loop strip closures together as necessary. This will make an envelope type pocket around the lower edge of the hardtop. Repeat on the passenger side.
5. Wrap and fasten any other flaps with hook and loop strip closures as needed.
6. Hardtop may now be hoisted into storage position and / or placed on storage rack.

#### CLEANING INSTRUCTIONS:

The cover can be washed in a normal household washing machine. Use only **COLD** water and mild soap on a **GENTLE CYCLE**. **NO BLEACH**. **AIR DRY.... NO HEAT**.